



dragonfly

motorized & tab-tension
film screens



RJ-11 Pin-Outs

Momentarily contact NEUTRAL wire and UP or DOWN or STOP wire for screen direction control

1. EMPTY
2. EMPTY
3. Dry Contact Control: Neutral Line
4. Dry Contact Control: Motor Stop
5. Dry Contact Control: Motor Down
6. Dry Contact Control: Motor Up

Manual Switch Plus Additional Control

Momentarily contact NEUTRAL wire and UP or DOWN or STOP wire for screen direction control

1. Dry Contact: Motor UP
2. Dry Contact: Stop
3. Dry Contact: Neutral
4. Dry Contact: Motor DOWN

