TROUBLESHOOTING

Wirepath structured wire modules are designed to function trouble-free. Most problems that occur are due to simple issues. If you have trouble, please check the list of simple fixes below. If the problem persists, contact your authorized Wirepath dealer or Wirepath customer service at 866.424.4489.

No Telephone signal

- Verify that there is signal on the input being used.
- Check all wiring connections on output(s) with no signal including any wall-plate connections at the remote location.
- Disconnect RJ-31X cable if this option is being used. Retry operation.
- Check jumper wire from WP-MOD-TEL1X6 if the only trouble is with locations connected to the WP-MOD-TELEXP8.

Lifetime Warranty

All Wirepath[®] products have a Lifetime Limited Warranty. This warranty includes parts and labor repairs on all components found to be defective in material or workmanship under normal conditions of use. This warranty shall not apply to products which have been abused, modified or disassembled. Products to be repaired under this warranty must be returned to the SnapAV or a designated service center with prior notification and an assigned return authorization number (RA).



Wirepath

10405 Granite Street Charlotte, NC 28273

704.927.7607 Tech Support: 1.866.424.4489

email: techsupport@snapav.com


WWW.SNApav.com ©2007 Snap AV • Charlotte, NC



INSTALLATION GUIDE

>>WP-MOD-TEL1X6 / TELEXP8

TELEPHONE MODULES



Thank you for purchasing a great item from one of the highest value lines in structured wiring available today, Wirepath. We appreciate your purchase and are committed to being the best choice for your needs.

The Episode WP-MOD-TEL1X6 and WP-MOD-TELEXP8 are superb choices for almost every type of home installation. They have been designed with advanced technology components that allow high performance while being flexible enough for any type of installation. Use other Wirepath structured wire items for your installation needs to get the best value possible in your systems.

IMPORTANT INSTRUCTIONS

- · Read and understand all instructions.
- · Do not use this product near water, such as a bath tub, wash bowl, sink, pool or in a wet basement.
- Never install wiring for telephones during a lightning storm.
- Never touch bare telephone wires or connections unless the main line has been disconnected at the interface.
- Use caution when installing, terminating or modifying any type of wire.

WIREPATH TELEPHONE MODULE FEATURES

TELEPHONE DISTRIBUTION FOR UP TO FOUR LINES TO SIX LOCATIONS

Maximize your flexibility by using Binary™ 8 conductor CAT5e UTP cabling.

TELEPHONE EXPANSION FOR UP TO FOUR LINES TO EIGHT LOCATIONS

The Wirepath WP-MOD-TELEXP8 can be easily added to the WP-MOD-TEL1X6 for expanding four lines to up to eight additional locations using a simple jumper cable.

RJ-31X JACK FOR EASY INTEGRATION WITH SECURITY SYSTEMS

This allows easy integration for security systems.

INSTALLATION


PLACING YOUR WIREPATH STRUCTURED WIRE MODULE

Wirepath structured wiring modules are designed to fit Wirepath structured wiring enclosures, but also fit most major brands of enclosures as well. Installation is simple with our familiar expansion pins. Plan the placement of each model in the enclosure based on how you have wire entering the enclosure and what will allow for the cleanest routing of wires.

If the Wirepath module is being used in an enclosure of another brand, it may be necessary to use one of the included spare mounting pins in the extra mounting flange hole and remove the two pins on that side to fit the mounting pattern of other enclosures from another brand.


TELEPHONE WIRING

A standard 110 punch down tool is all that is required to properly connect the wiring to the module. Please see illustration.



RJ-31X WIRING (WP-MOD-TEL1X6 only)

If it is necessary to interface the telephone wiring with a security system, simply use the provided jack. Follow the illustration below if you need to make a cable for this use.



EXPANSION PORT

If it is necessary to expand beyond six locations, connect the WP-MOD-TELEXP8 with an 8 conductor jumper cable. Multiple WP-MOD-TELEXP8 modules can be daisy-chained. The limit of total units possible will vary based on the installation.

